


Water supply adapter



water. It is designed to transform your tap water into good tasting water.

 Reverse Osmosis Unit Water storage tank Installation kit consists tank ball valve, drain saddle valve, feed water adapter, faucet assembly, tubing, tube inserts. Installation manual

Read carefully and follow the instruction in this manual before proceeding with actual installation. Failure to do so could result in personal injury or damage to the equipment or other properties. Be sure to follow any special plumbing codes in

vour area.

CHECK LIST:

- Bottom filter housing wrench tube insert * ½" feed water adapter for water supply Inline Ball valve (On/Off valve)

INSTALLATION KIT:

Tank ball valve Drain saddle clamp


¼" tubing

Chrome dispensing faucet

3/8" compression brass adapter for water

Replacement filter Part no. 225

Replacement filter Part no. IC21



 If feed water has hardness level above 300 ppm, we recommend putting a water softener prior to the RO system. If feed water has iron, rust problem, we recommend putting an iron filter prior to the RO system. If feed water has bacteria problem, we recommend putting an ultra violet sterilizing system prior to RO system.

Do not connect the system to HOT water supply.

Koolermax 6- Stage Reverse Osmosis + Alkaline filter Water Purification Systems

Incorrect installation will VOID the warranty.

WARNING: Input pressure must not exceed 80 psi. Pressure regulator must be installed to reduce pressure. WARNING: Filter housings need to be replaced every 3 years to avoid cracks due to material fatique, thermo and

quality.

WARNING:

WARNING:

WARNING:

pressure stress. PRODUCT SPECIFICATION

Storage Tank: Pressurized tank with pre-charge pressure of 5 to 7 psi, powder coated steel construction with Food

Capacity: Generates 50 to 75 gallons per day depends on water temperature, pressure, chemistry variations

Do not use this RO system alone to treat water with bacteria problem or water source with unknown

Hardware: feed water adapter, feed water valve, drain saddle valve, tank valve, and screws. Installation & Service manual

Model no: K-6A Alkaline

System includes

RO unit:

Working temperature: $100 \sim 40$ deg. F (37C ~ 4 deg. C) pH range: 4-10 If feed water has hardness level above 300 ppm, we recommend putting a water softener prior to the RO system.

Water Dispensing Faucet: lead-free, long reach goose neck type, polish chrome finish.

- If feed water has bacteria problem, we recommend putting an ultra violet sterilizing system prior to RO system. Filter Service Life
- 3rd Stage Carbon block filter: Recommend changing every 6~12 months. 4th Stage <u>TFC membrane</u>: Recommend changing every 2~3 years. Replacement filter Part no. M75
- Dimension

5th Stage Alkaline filter: Recommend changing every 12 months

Warranty

Average Rejection rate: 92 to 98% of dissolved solids after RO

Purification Processes/ Filter specifications Removes microbiological contaminants like Cysts (protozoan), inorganic/Radiological contaminants like Barium,

Cadmium, Copper, Chromium (hexvavalent), Chromim (trivalent), Fluoride, Lead, Radium 226/228, Selenium, etc. Ammonia, Arsenic, chloramines, chlorine, copper, lead, nitrate, phosphate, silica, hardness, calcium, magnesium, other dissolved solids.

1st stage: 5 micron sediment filter, 3" x 9 7/8" height, made by 100% pure polypropylene fibers

6th stage: Inline carbon filter (polishing filter, improves taste): 2" x 10"

2nd & 3nd stage: carbon filter, 3" x 9 3/4" height, composed of high-performance coconut shell carbon. 4th stage: TFC type membrane, 75 GPD, 1 3/4" x 11 3/4" long

System Requirements Working pressure: 40 to 80 psi feed water pressure required, if below 40 psi, a booster pump is needed. We have a RO system with built-in booster pump assembly. If the input pressure is above 80 psi, you MUST put a pressure regulator to reduce the pressure below 80 psi. (We do supply the optional pressure regulator)

RO unit: 6-stage unit, all filters included.

Grade butyl water bladder. NSF listed

1st Stage Sediment filter: Recommend changing every 6~12 months. Replacement filter Part no. SF05 2nd Stage Carbon block filter: Recommend changing every 6~12 months. Replacement filter Part no. C10 Replacement filter Part no. C10

If feed water has iron, rust problem, we recommend putting a iron filter prior to the RO system.

6th Stage <u>Inline carbon filter</u>: Recommend changing every 6 ~12 months.

Length 15 inch, Width 5 1/2 inch, Height 16 inch

Diameter 9 inch, Height 14 inch, holds 2 gallons Storage tank: 9 1/2 inch above counter top Faucet: 1 year Limited Warranty on parts, components. Filters are not under warranty.

5th stage: Alkaline filter: add a little Calcium and Magnesium back to the water to increase pH to 8.5 to 9.5